






TV System selection / Selección de Sistema TV



Channel selection and adjustment
Ajuste y selección de canal



Output Channel selection
Selección de Sistema TV

CM01 VHF

System/Sistema	Channel No. / Canales
B E05	1
L L05	2 3 4 5 6
I I04	2 3 4 5 6
D R06	2 3 4 5 6
E06	2
L06	1 3 4 5 6
I05	1 3 4 5 6
R07	1 3 4 5 6
E07	1 2
L07	1 2
I06	3 4 5 6
R08	3 4 5 6
E08	3
L08	3
I07	1 2 4 5 6
R09	1 2 4 5 6
E09	1 3
L09	1 3
I08	2 4 5 6
R10	2 4 5 6
E10	2 3
L10	2 3
I09	1 4 5 6
R11	1 4 5 6
E11	1 2 3
L11	1 2 3
I10	4 5 6
R12	4 5 6
E12	4
L12	1 2 3 5 6
I11	1 2 3 5 6
R13	1 2 3 5 6
S11	1 4
L13	2 3 5 6
I12	2 3 5 6
R14	2 3 5 6
S12	2 4
L14	1 3 5 6
I13	1 3 5 6
R15	1 3 5 6
S13	1 2 4
L15	1 2 4
I14	3 5 6
R16	3 5 6
S14	3 4
L16	1 2 5 6
I15	1 2 5 6
R17	1 2 5 6
S15	1 3 4
L17	2 5 6
I16	2 5 6
R18	2 5 6
S16	2 3 4
L18	1 5 6
I17	1 5 6
R19	1 5 6
S17	1 2 3 4
L19	5 6
I18	5 6
R20	5 6
S18	5
S21	5
I19	1 2 3 4 6
R21	1 2 3 4 6

System/Sistema	Channel No. / Canales
B E 05... E12, S11...S25	
L L 05... L19, S21...S25	
I I 04... I19, S21...S25	
D R06... R21, S21...S25	

System/Sistema	Channel No. / Canales
ITALY B III	
CH D	1 2 3 4 5 6
CH E	1 2 3 4 5 6
CH F	1 2 3 4 5 6
CH G	1 2 3 4 5 6
CH H	1 3 4 5 6
CH H1	1 2 3 4 5 6
CH H2	1 2 3 4 5 6

CM01 UHF

System/Sistema	Channel No. / Canales
21	1 2 3 4 5 6
22	2 1 3 4 5 6
23	1 2 3 4 5 6
24	3 1 2 4 5 6
25	1 2 3 4 5 6
26	1 2 3 4 5 6
27	1 2 3 4 5 6
28	4 1 2 3 5 6
29	1 2 3 4 5 6
30	2 4 1 3 5 6
31	1 2 4 3 5 6
32	1 2 3 4 5 6
33	1 2 3 4 5 6
34	2 3 4 1 5 6
35	1 2 3 4 5 6
36	1 2 3 4 5 6
37	1 2 3 4 5 6
38	2 1 3 4 5 6
39	1 2 3 4 5 6
40	1 2 3 4 5 6
41	1 2 3 4 5 6
42	1 2 3 4 5 6
43	1 2 3 4 5 6
44	1 2 3 4 5 6
45	1 2 3 4 5 6
46	2 4 1 3 5 6
47	1 2 3 4 5 6
48	1 2 3 4 5 6
49	1 2 3 4 5 6
50	2 3 4 1 5 6
51	1 2 3 4 5 6
52	1 2 3 4 5 6
53	1 2 3 4 5 6
54	2 1 3 4 5 6
55	1 2 3 4 5 6
56	1 2 3 4 5 6
57	1 2 3 4 5 6
58	1 2 3 4 5 6
59	1 2 3 4 5 6
60	4 1 2 3 5 6
61	1 2 3 4 5 6
62	2 4 1 3 5 6
63	1 2 3 4 5 6
64	1 2 3 4 5 6
65	1 2 3 4 5 6
66	2 3 4 1 5 6
67	1 2 3 4 5 6
68	1 2 3 4 5 6
69	1 2 3 4 5 6

System/Sistema	Channel No. / Canales
G CH 21...CH69	
L CH 21...CH69	
I CH 21...CH69	
K CH 21...CH69	

CM01 VHF AU/NZ

AU.....06	1
NZ.....04	2 3 4 5 6
AU.....07	2
NZ.....05	1 3 4 5 6
AU.....08	1 2
NZ.....06	3 4 5 6
AU.....09	3
NZ.....07	1 2 4 5 6
AU.....09A	1 3
NZ.....08	2 4 5 6
AU.....10	2 3
NZ.....09	1 4 5 6
AU.....11	1 2 3
NZ.....10	4 5 6
AU.....12	4
NZ.....11	1 2 3 5 6
AU.....S11	1 4 2 3 5 6
AU.....S12	2 4 1 3 5 6
AU.....S13	1 2 4 3 5 6
AU.....S14	3 4 1 2 5 6
AU.....S15	1 3 4 2 5 6
AU.....S16	2 3 4 1 5 6
AU.....S17	1 2 3 4 5 6
AU.....S18	1 2 3 4 5 6
AU.....S19	1 5 2 3 4 6
AU.....S20	2 5 1 3 4 6
AU.....S21	1 2 5 3 4 6
AU.....S22	3 5 1 2 4 6
AU.....S23	1 3 5 2 4 6
AU.....S24	1 3 5 2 4 6
AU.....S25	1 2 3 5 4 6

CM01 UHF AU/NZ

AU.....C20	1
NZ.....C21	2 3 4 5 6
AU.....C21	2
NZ.....C22	1 3 4 5 6
AU.....C22	1 2
NZ.....C23	3 4 5 6
AU.....C23	3
NZ.....C24	1 2 4 5 6
AU.....C24	1 3
NZ.....C25	2 4 5 6
AU.....C25	2 3
NZ.....C26	1 4 5 6
AU.....C26	1 2 3
NZ.....C27	4 5 6
AU.....C27	4
NZ.....C28	1 2 3 5 6
AU.....C28	1 4
NZ.....C29	2 3 5 6
AU.....C29	2 4
NZ.....C30	1 3 5 6
AU.....C30	1 2 4
NZ.....C31	3 5 6
AU.....C31	3 4
NZ.....C32	1 2 5 6
AU.....C32	1 3 4
NZ.....C33	2 5 6
AU.....C33	2 3 4
NZ.....C34	1 5 6
AU.....C34	1 2 3 4
NZ.....C35	5 6
AU.....C35	5
NZ.....C36	1 2 3 4 6
AU.....C36	1 5
NZ.....C37	2 3 4 6
AU.....C37	2 5
NZ.....C38	1 3 4 6
AU.....C38	1 2 5
NZ.....C39	3 4 6
AU.....C39	3 5
NZ.....C40	1 2 4 6
AU.....C40	1 3 5
NZ.....C41	2 4 6
AU.....C41	2 3 5
NZ.....C42	1 4 6
AU.....C42	1 2 3 5
NZ.....C43	4 6
AU.....C43	4 5
NZ.....C44	1 2 3 6
AU.....C44	1 3 4 5
NZ.....C45	2 3 6
AU.....C45	2 4 5
NZ.....C46	1 3 6
AU.....C46	1 2 4 5
NZ.....C47	3 6
AU.....C47	3 4 5
NZ.....C48	1 2 6
AU.....C48	1 3 4 5
NZ.....C49	2 6
AU.....C49	2 3 4 5
NZ.....C50	1 6
AU.....C50	1 2 3 4 5
NZ.....C51	3 6
AU.....C51	3 4 5
NZ.....C52	1 2 3 4 5 6
AU.....C52	1 3 4 5 6
NZ.....C53	2 3 4 5 6
AU.....C53	2 3 4 5
NZ.....C54	1 3 4 5 6
AU.....C54	1 3 4 5
NZ.....C55	5 6
AU.....C55	5 6
NZ.....C56	1 2 4 5 6
AU.....C56	1 3 5 6
NZ.....C57	2 4 5 6
AU.....C57	2 3 5 6
NZ.....C58	1 3 4 5 6
AU.....C58	1 2 3 5 6
NZ.....C59	4 5 6
AU.....C59	4 6
NZ.....C60	1 2 3 5
AU.....C60	1 4 6
NZ.....C61	2 3 5
AU.....C61	2 4 6
NZ.....C62	1 3 5
AU.....C62	1 2 4 6
NZ.....C63	3 5
AU.....C63	3 4 6
NZ.....C64	1 2 5
AU.....C64	1 3 4 6
NZ.....C65	2 5
AU.....C65	2 3 4 6
NZ.....C66	1 5
AU.....C66	1 2 3 4 6
NZ.....C67	5
AU.....C67	5 6
NZ.....C68	1 2 3 4 6
AU.....C68	1 3 4 5 6
NZ.....C69	2 3 4
AU.....C69	2 3 4 5 6
NZ.....C70	3 4
AU.....C70	3 5 6
NZ.....C71	1 2 4
AU.....C71	1 3 5 6
NZ.....C72	2 4
AU.....C72	2 3 4 5 6
NZ.....C73	1 4
AU.....C73	1 2 3 5 6
NZ.....C74	4
AU.....C74	1 2 3 5 6
NZ.....C75	4 5 6
AU.....C75	1 2 3